

The installation instruction of W208, R170, W168 mirror cover with light (arrow type) and manner light

1. The following parts are included in the kit:



2 pcs mirror cover 2 pcs arrow type indicator
2 pcs mirror cover frame 2 pcs manner light



8 pcs extra wires 14 pcs screws
8 pcs stripping quick splice connector

2. Remove the factory mirror from your W208, R170, W168 car.

3. Remove the factory glass, mirror cover and frame. And keep the mirror holder and motor.
See picture 2 & 3



Picture 2



Picture 3

4. Fixed arrow type indicator and manner light onto the mirror cover (See picture 4, 5 and 6).
And fixed mirror holder and motor with the new mirror cover with light (arrow type) and manner light, frame one by one then use the screws to screw the mentioned 3 components together (See picture 7, 8,9 and 10).



Picture 4



Picture 5



Picture 6



Picture 7



Picture 8



Picture 9



Picture 10

5. Reinstall the glass to the correct position of mirror holder and motor.

6. The door mirror cover with light is installed completed. See picture 11.



Picture 11